




## OPERATING MANUAL

TUF-DLD300



1


Note: This product does not contain a laser. However, when working with laser tools, obey the safety instructions for the particular instrument.

### Specification


Leveling Sensitivity (High):	1mm
Leveling Sensitivity (Normal):	2mm
Leveling Sensitivity (Low):	5mm
Leveling Sensitivity (Lowest):	10mm
Laser Reception Window Width:	135mm
Working radius	≥300m
Bubble Vial Accuracy:	30"/2mm
Operation Time:	24h (no illuminate LCD)
Auto Power Off (with No Signal Detected):	30min
Power Supply:	4 × AA batteries (Alkaline)
IP Rating:	IP54
Operating Temperature Range:	-10 ~50
Storage Temperature Range:	-20 ~60

Attention: Working radius depends on the model of laser instrument.

2



3



4


### Batteries and Power

#### Battery Installation/Removal

1. Open Battery Cover.
2. Install new batteries correctly. Orient batteries correctly when placing into laser unit.
3. Securely close and lock battery cover.

Warning: Pay close attention to the battery holder's (+) and (-) markings proper battery insertion.

Batteries must be same type and same capacity. Do not use a combination of batteries with different capacities remaining



5


### Rod Clamp

Detector can be used in hand or with optional clamp to mount the detector to a measuring rod, pole, or similar object.

To mount clamp onto detector (see figure)

Guide the clamp towards the detector using the alignment hole.

Tighten the fixing screw.




- (1) Alignment Points - help secure and align rod clamp.
- (2) Captive Rod Clamp Screw - attaches to the back of detector.
- (3) Alignment Points - help secure and align rod clamp.
- (4) Reversible Face-slanted face for round and oval rods; flat face for rectangular and square rods.
- (5) Clamping Screw Knob - secures clamp to rods by moving the traveling jaw. Clockwise tightens; Counterclockwise loosens.

6

## Operation

### Power On/Off Illumination On/Off



- Power On/Off**
1. Press Power key to turn detector ON
  2. When powered ON, the entire LCD will momentarily display all icons (this allows a check to ensure that LCD is functioning correctly).
  3. Press and hold for ≥3 seconds to turn detector OFF.

NOTE:


The detector will automatically power OFF after 30 minutes of not detecting a laser beam to conserve battery. To power ON again, press .

- Illuminate LCD**
1. When detector is ON, press to turn ON/OFF LCD illumination.

NOTE:

The illumination will automatically turn OFF after 10 minutes of not detecting a laser beam and no operation. 7

### Speaker Type



- Sound High -----
- Sound Low -----Voice
- Sound -----Mute

When powered ON, Buzzer type is setting ON by default.

8