

Settings


1.1 →

2.1 / → →

3.1 / → ON → OFF

Change settings in submenu / turn function ON/OFF

2 sec.




Bluetooth / NFC

1.1 →

2.1 / → →

Transfer value from main line Turn function ON/OFF

2 sec.





Memory

Navigate through last 30 values

Clear memory:

+ 2 sec.



Quick Start

Leica DISTO™ D2/D2G



- 1 Display
- 2 ON/Measure
- 3 Add
- 4 Clear/OFF
- 5 Memory/Timer
- 6 Measuring Reference
- 7 Bluetooth/ NFC
- 8 Functions/ Settings
- 9 Subtract

2 sec.  **5**

Timer




Adjust delay of automatic release

+ **-**

FUNC **2x** 


Volume



FUNC **2 sec.** 


FUNC **4x** 

Smart Horizontal



FUNC **6x** 

Stake-out




www.disto.com

User Manual:




FUNC **1x** 

Area



FUNC **3x** 


Triangle Area



FUNC **2 sec.** 


FUNC **5x** 

Pythagoras (3-point)



FUNC **7x** 

Levelling



 **ON** 

 **OFF** 

2 sec.

